



1008A	FUNCTION
1	INPUT
2	INPUT
3	GND
4	GND
5	N.C.
6	OUTPUT
7	-27VDC

= Nominal DC Voltages
 Use VTVM or FETVM

C PART NUMBERS ARE MY OWN, NOT SPARTA'S. PIN NUMBERS ARE SPARTA'S

B REDRAWN BY DAVID WIGFIELD 3-29-18

A THIS SCHEMATIC WAS DRAWN FROM A 1008A PRE-AMP IN SPARTA AS-30 CONSOLE SERIAL NUMBER 212. IT REFLECTS THE CONSOLE IN MY POSSESSION AND MAY OR MAY NOT BE REPRESENTATIVE OF ALL 1008A PRE-AMPS MANUFACTURED BY SPARTA ELECTRONICS.

THE DRAWING IS AS ACCURATE AS I CAN MAKE IT BUT IT MAY CONTAIN ERRORS THAT I DID NOT CATCH. USE CAUTION! I AM NOT RESPONSIBLE FOR ANY PROBLEMS YOU MAY ENCOUNTER WHEN USING THIS ON YOUR OWN CONSOLE!
 USE THIS DRAWING AT YOUR OWN RISK!



If You Didn't Get This From My Site,
 Then It Was Stolen From...

www.SteamPoweredRadio.Com



TITLE
 1008A
 MICROPHONE PREAMP

DRAWN. **SMU** DATE. **8-28-67**
 APPD. **RKO** DATE. **2-9-68**

SHT OF
 1 1

DWG. NO.
 S-110G